



The repair, exchange, and replacement parts list for Encore computers, Gould computers, and SEL computers appears below, and includes parts for Encore computers 32/27, 32/67, 32/77, 32/87, 32/97, and RSX systems as well as PowerTec, LH Research, and Switching Power, Inc. power supplies. Compro is the OEM for Encore parts. **NOTE:** If you need a SEL/Gould/Encore computer part that is not listed below, contact us for availability. To request a quote, call 1-800-936-2673 or email us at info@compro.net.

Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
105-103016-001	ASSY-RTP/SERIAL/INTFC
105-103041-005	ASSY-SER/CTRL
105-103044-001	ASSY-AC/DISTR/PNL
105-103044-002	ASSY-AC/DISTR/PNL
105-103047-001	ASSY-CTRL/PNL/PR
105-103108-001	ASSY-RS-422/DISTR
105-103147-001	ASSY-PDU/115V
105-103147-002	ASSY-PDU/230V
105-103294-004	ASSY-TAPE/DR
105-103294-006	ASSY-MDL/8MM/CART/TP
105-103309-002	4/SLOT RMC CHASSIS
105-103312-002	ASSY-P/S MOD 1200W
107-103556-001	SUBASSY-PWR/SPLY
107-103743-001	SUBASSY-RMS/CHASSIS
107-103746-001	ASSY/RMC
107-103747-001	SUBASSY-SCSI/ADAPTER
107-103865-003	ASSY-4GB/DISC
118-103120-001	KIT-CPU* CHECK W
118-103244-001	KIT-FLG/PT/CU/M
118-103260-002	DISC*PRCS II
118-103284-001	KIT-INT/PROC/UNI
118-103972-002	KIT-CPU/4/PRCS/1
118-103972-012	CPU/4P
118-103972-013	KIT 64MB DRAM/2CPU
118-103972-014	CPU/4P/128K/64MB
118-113049-021	KIT-CPU/4P/128K/16MB
118-113049-022	KIT-CPU/4P/128K/64MB
118-113049-042	KIT-CPU/4P/512K/64MB
118-113049-122	KIT-CPU/4P/128K/64MB
118-113049-142	KIT-CPU/4P/512K/64MB
118-113058-001	KIT-6U/RMS/INTFC
118-113059-001	KIT-CPU/4P/1MB/144MB
118-113081-002	KIT-256MB/MCA



Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
118-113103-001	KIT-TRANS
119-103294-001	MODIFICATION TO HSDI
119-103421-001	5FT SURF TRANS CBL MOD
160-103007-001	PWA-LGC/TERM/INT
160-103007-005	PWA-LGC/TERM/IN
160-103023-001	PWA-MHD/CTRL
160-103025-001	PWA-ADS/INTFC*
160-103026-005	PWA-EXT/INTRPT
160-103028-002	PWA-PFS/120HZ
160-103033-001	PWA-GPMC*
160-103033-002	PWA-GPMC*
160-103054-001	PWA-ADI*
160-103063-001	PWA-UNIV/I/O
160-103063-007	PWA-UNIV/I/O
160-103078-004	PWA-GPDC/TERM
160-103109-001	PWA-RTOM
160-103122-001	PWA-MTC*
160-103175-001	TLC CARD READER
160-103210-001	PWA-MTC
160-103227-001	PWA-PFS/MDL
160-103227-002	PWA-PFS/MDL
160-103260-001	PWA-SS/RAM*
160-103265-002	MBC/SCM 600
160-103282-001	PWA-DEV/INT
160-103298-001	PWA-PWR/FAIL/CONV
160-103302-001	PWA-CLK/RPTR
160-103302-002	PWA-CLK/RPTR
160-103305-006	PWA-BUS/TERM/WO/
160-103305-007	PWA-TERM
160-103305-008	PWA/BUS/TERM/PRI
160-103305-105	PWA-INT/CLK
160-103305-106	PWA-BUS/TERM/W/O/CLK
160-103305-107	PWA-BUS/TERM/W/CLK
160-103306-001	PWA-IOX
160-103321-001	PWA-PER/SW/CONTROL
160-103323-001	PWA-MUXP/PRPHL/S
160-103325-001	PWA-MUXP/RS232/S
160-103364-001	PWA-HSD/MULTIWI



Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
160-103336-001	PWA-PWR/FAIL/DISTR
160-103367-001	PWA-BKPLN/LGC/MEM
160-103369-001	PWA-HSTP/DI
160-103371-001	PWA-BTRY/ADPT
160-103385-001	PWA-SHIFTER/"S"
160-103419-001	PWA-CPU/MULTIWIR
160-103424-001	PWA-IOP/(MULTIWIR
160-103431-001	PWA-DEV/INTFC
160-103433-001	PCB 27 CPU DI
160-103433-002	PWA-DEV/INTFC/C
160-103434-001	PWA-DISTR/PNL/RS232
160-103439-001	PWA-BKPLN/LGC/I
160-103440-001	PWA-BKPLN/I/O
160-103442-001	PWA-DISTR/PNL
160-103446-001	PWA-DISTR/PNL/RS423
160-103448-001	PWA-LP/FDC
160-103449-001	PWA-IOP/BUS/TERM
160-103463-001	PWA-FP/ADD/SUB
160-103464-001	PWA-FP/MULTI
160-103465-001	LSTP D/I
160-103468-001	PWA-EXEC/"E"
160-103478-005	PWA-1MB/IMM
160-103479-001	PWA-MULTI/ACLTR
160-103480-001	PWA-MULTI/ACLTR
160-103488-001	PWA-EXEC/"D"
160-103489-001	PWA-IOP/DISC/
160-103496-001	PWA OPERAND/ADDR
160-103497-001	PWA-BKPLN
160-103497-002	PWA-BKPLN
160-103493-002	PWA-CACHE/BFR
160-103507-001	PWA BKPLN/IPU
160-103507-002	PWA-BKPLN/IPU
160-103508-001	PWA-CLK/"K"
160-103509-001	PWA-IOP/DI
160-103510-001	PWA-EXEC/"F"
160-103511-001	PWA-ADRS/SET/UP
160-103518-002	PWA-Z/CD/INTFC
160-103519-001	PWA-IOP



Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
160-103521-001	PWA-INSTM
160-103522-001	PWA-DIAG/PRCSR
160-103526-001	PWA-CPU/SGL/SLOT
160-103533-001	PWA-TLTN/"T"
160-103535-001	PWA-IEEE-488
160-103538-001	PWA-MPCI
160-103539-001	PWA-FOREPLANE
160-103541-001	PWA-MT/CART/SW
160-103542-001	PWA-LP/CR/SW
160-103543-001	PWA-RS423/TO/RS422
160-103544-001	PWA-IOP/DISC/CO
160-103553-001	PWA-CONNECTION
160-103554-001	PWA-HSDI
160-103556-001	COPPER FPU
160-103557-001	COPPER FPU-B BOARD
160-103562-001	PWA-2MB/MEMORY
160-103562-002	PWA-MEM/MDL/1MB
160-103563-001	PWA-MICRO/STRO
160-103563-002	PWA-MICRO/STOR
160-103564-001	PWA-CACHE/BFR
160-103564-002	PWA-"B2"/BD
160-103568-001	MICRO SEQ ASSY
160-103583-001	PWA-CACHE/SELBUS
160-103584-001	PWA-INSTR/EXEC
160-103586-001	PWA-ADRS/SETUP
160-103588-001	PWA-CACHE/CONT/III
160-103593-001	PWA-LOOKASIDE/BFR
160-103597-001	PWA-SMC2/PRIME
160-103602-002	PWA-SYNC/COMM/MUX
160-103604-001	PWA-SMCI
160-103605-001	PWA-SMC2
160-103606-001	PWA-MBI/DI
160-103607-001	PWA-MBI
160-103608-001	PWA-SPI/DI
160-103609-001	PWA-SELBUS/INTFC
160-103610-002	PWA-INSTR/SETUP
160-103611-001	PWA-OPERAND/ADRS
160-103612-001	PWA-LPFD/CONT



Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
160-103616-001	PWA-CLK/IV
160-103619-001	PWA-ASSY/BFR
160-103621-001	PWA-URMPC
160-103622-001	PWA-DSPL/TNKEY
160-103623-001	PWA-UDP
160-103627-001	PWA-MUXP/DP/IOP/DC*
160-103635-001	PWA-NTDS/PRL/INTFC
160-103635-002	PWA-NTDS/PRL/INTFC
160-103640-001	PWA-BTP
160-103641-001	PWA-DISTR
160-103645-001	PWA-BKPLN(97)
160-103646-001	PWA-BKPLN/IPU
160-103654-002	PWA-CPU/IPU/MSI
160-103656-001	PWA-CPU/IPU/IE2
160-103666-001	PWA-RS232/INTFC
160-103667-001	PWA-V35/INTFC
160-103669-001	PWA-REGIONAL/PROC*
160-103674-002	PWA-SC27/CPU/PPU
160-103675-001	PWA-ENET/BRDG
160-103690-001	PWA-DPNL/8-LINE
160-103691-001	PWA-PSM/CONT
160-103691-002	PWA-PSM/CONT
160-103695-001	PWA-EXEC/"G"
160-103696-001	PWA-EXEC/"E"
160-103702-001	PWA-AIRS/PNL*
160-103703-001	PWA-ASYNC/INTFC*
160-103723-001	PWA-4MB/ISM
160-103723-002	PWA-2MB/ISM
160-103728-001	PWA-BKPLN/10/4
160-103735-001	PWA-BKPLN/8/0
160-103743-001	PWA-MP/BUS/SW
160-103758-001	PWA-ASSY/BKPLN
160-103759-001	PWA-ASSY/BKPLN
160-103768-001	PWA-8/LINE/CONT
160-103769-001	PWA-WRT/GEN/CONT
160-103770-002	PWA-READ/SENSE/CONT
160-103775-001	PWA-PRPHL/SW/MOD/HSD
160-103784-001	PWA-DUAL/INTFC/CONT



Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
160-103803-001	PWA-CMOS/CPU
160-103813-001	PWA-A/D/INTFC
160-103831-001	PWA-DRX/W/X
160-103831-002	PWA-DRX/B/W
160-103834-001	PWA-EXT/TERM*
160-103835-001	PWA-MIDP
160-103835-002	MIDP SLV 8DR OPT
160-103835-003	PWA-MULTI/PROC
160-103844-001	PWA-512KB/SHAD/MEM
160-103845-001	PWA-2MB/DPIMM
160-103845-002	PWA-2MB/SPIMM
160-103845-003	PWA-8MB/DPIMM
160-103845-004	PWA-8MB/SPIMM
160-103858-001	PWA-HSDP
160-103866-001	PWA-CACHE TERMINATED
160-103866-002	PWA-CACHE NON-TERM.
160-103873-001	PWA-MFP
160-103874-001	PWA-MFP/DI
160-103885-001	PWA-MFP/DI/II
160-103892-001	BACKPLANE 7/0
160-103894-001	PWA-PTR/INTFC
160-103901-001	PWA-IEEE/BUS/CONT
160-103904-001	PWA-HARM/TERM*
160-103904-002	PWA-LL/HARM
160-103905-001	PWA-SCU
160-103906-001	PWA-VCU
160-103919-001	PWA-NBIC
160-103943-001	PWA-T1/DI*
160-103949-001	PWA HSD TERMINATOR
160-103963-001	UNIVERSAL/DRX*
160-103964-001	PWA-FPA
160-103965-001	PWA-TI/CONT*
160-103997-001	PWA-SCSI/PRPHL/BKPLN
160-103998-001	PWA-TELEDIA/C/S
160-113005-001	PWA-ITEM
160-113011-001	PWA-4MB/SHADOW/MEM TERMINATED
160-113011-002	PWA-4MB/SHADOW/MEM NON-TERM.
160-113021-001	PWA-HSDRX*



Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
160-113116-004	PCB 3030 SRAM 4MB 150NS
160-113121-001	PWA-MFP/DI/SD
160-113121-002	PWA-MFP/DI/S/D
160-113125-001	PWA-CLK/TERM
160-113132-001	PWA-2040/CPU
160-113132-002	PWA-2030/CPU
160-113143-001	PWA-MFP/S/D
160-113145-001	PWA-ENET/PLUS/CONT*
160-113163-001	PWA-16MB/DPIMM
160-113163-002	PWA-16MB/DPIMM
160-113163-003	PWA-64MB/DPIMM
160-113164-001	PWA-APB
160-113168-002	PWA-DMT/RMS
160-113169-001	PWA-DMR/RMS
160-113172-001	PWA-MMHSDI
160-113184-001	PWA-SPSC/PNL
160-113194-001	PWA-PHY/PARA/MON
160-113196-001	PWA-QSSC/DI
160-113197-001	PWA-QUAD/PORT/X.25
160-113199-001	PWA-CLK/DISTR
160-113203-001	PWA-EXT/INT
160-113212-012	PWA-64MB/MEM
160-113219-002	PWA-FRC
160-113229-001	PWA-4MB/SRAM/75NS
160-113229-002	PWA-4MB/SRAM/150
160-113229-003	PWA-16MB/SRAM
160-113234-001	PWA-CPU
160-113234-002	PWA-CPU
160-113235-001	PWA-SCC/II
160-113249-001	PWA-CPU/RSX
160-113251-001	PWA-MCP
160-113253-001	PWA-REF/MEN/TRSMTR II
160-113254-001	PWA-REF/MEN/RCVR/II
160-113255-001	PWA-RMS/II
160-113258-001	PWA-4MB/RMS/II
160-113258-002	PWA-16MB/RMS
160-113258-003	PWA-RMS/4MB
160-113258-004	PWA-16MB/RMS



Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
160-113258-111	PWA-RMSII,4MB
160-113260-001	PWA-RMS/PORT
160-113261-001	PWA-SER/PORT/INTFC
160-113262-001	PWA-RMSII/I/O
160-113262-002	PWA-RMSII/I/O
160-113270-201	PWA-91/CPU/16MB
160-113271-001	PWA-16MB/MEM
160-113271-002	PWA-64MB/MEM
160-113271-003	PWA-256MB/MEM
160-113272-001	PWA-GIGABAUD/CHK
160-113273-001	PWA-RPC-II
160-113274-001	PWB ASSY, R.M.I.
160-113274-002	PWA-RMI
160-113281-001	PWA-MC/BRIDGE
160-113282-001	PWA-MC/BRIDGE
160-113286-001	PWA-CPU/4P/128K
160-113286-002	PWA-CPU/2P/128K
160-113372-001	PWA-BMC/TBAR
160-113373-001	PWA-CPU/4P/32MB
160-113379-001	PWA-ALPHA/RTOM
160-113382-001	PWA-PCI/FIBER/CHANNEL
160-113436-003	PWA-PCI/RMS/8MB
160-113439-003	PCA-PCI RMS (6U), DEC
221-200019-003	CRT-AMBER
221-300115-503	102GB DISC DRIVE
221-300116-003	SCSI/ADAPTER
221-300119-002	SCSI/DISK/DR/24MB
221-300122-001	TAPE/DR
221-300128-001	1/4"/TAPE/DR
221-500039-123	PWA- VME/ETHERNET/ CONT
221-700027-001	PWA-VME/HSD
221-800067-001	PWA-1553/BUS/CONT
221-800069-001	CRT/CONSOLE
221-800069-003	COLOR/MON/120V/60HZ
221-800069-007	KYBD
269-100024-001	PWR/SPLY
269-100024-002	PWR/SPLY
269-100029-001	PWR/SPLY



Parts Repair, Exchange and Remanufactured Equipment	
Part No.	Description
269-100029-002	PWR/SPLY
269-100029-003	PWR/SPLY
269-100029-004	PWR/SPLY
269-100031-001	PWR/SPLY
269-100031-002	PWR/SPLY
269-100037-001	PWR/SPLY
269-100037-002	PWR/SPLY
269-100040-001	PWR/SPLY
269-100040-002	PWR/SPLY
269-100041-001	PWR/SPLY
269-100041-002	PWR/SPLY
269-100045-001	PWR/SPLY*
269-100046-001	PWR/SPLY
269-100046-003	PWR/SPLY
269-100046-004	PWR/SPLY
269-100051-001	PWR/SPLY
269-100052-001	PWR/SPLY
269-100052-002	PWR/SPLY
269-100058-001	PWR/SPLY
269-100058-002	PWR/SPLY
269-100062-001	PWR/SPLY
269-100071-003	PWR/SPLY
269-100086-001	PWR/SPLY
269-100087-001	PWR/SPLY
269-100087-002	PWR/SPLY
269-100092-001	PWR/SPLY
269-100093-001	PWR/SPLY
269-100117-001	PWR/SPLY-700W/AC